

Getting Started Guide



Mobile Magic Carpet

Overview

- The Magic Carpet is an innovative interactive floor projection system that enables users to engage with games and images simply by moving on or over the projected surface.
- The system encourages user interaction and teaches cause and effect in a fun and intuitive way.

Step by Step

Start Up

1. **Turn on the PC** – the button can be found on the right hand side of the white box at the bottom of the unit
2. **Turn on the Projector** – this should automatically turn on when PC powers up. If it doesn't then press the button on the front of the white box at the bottom of the unit and it will turn blue.
3. Once the PC has booted up, the magic carpet software will start up automatically and show you the

latest and most recent used applications.

4. **Select the program – using keyboard** provided.

Depending on your software version, the full list of applications can be accessed by selecting the menu icon or categories icon from the top tool bar. Select application. To get out of a application, **press “esc”** on the keyboard and select again.

5. **Select the program – using Ipad or smart phone.**

Connect to Magic carpet wifi network within the settings of your iPad or Smart Phone. The password is **magiccarpet**. Click on the Magic carpet icon on your iPad or smartphone. If you are asked for an IP address in the set up page enter **192.168.0.200** (this is will be asked on the first use)

The Magic carpet screen will appear. Depending on your software version, the full list of applications can be accessed by selecting the menu icon or categories icon from the top tool bar. Select application. To choose a new program, select another application.

6. **To adjust the sound** – the up and down arrow buttons can be found on the left hand side of the white box at the bottom of the unit.

7. **To adjust the height** – the up and down arrow buttons can be found on the back of the white box towards the top. Device up – image bigger/ Device down – image smaller

Shut Down

1. **Shut down the Magic carpet** – exit the application (if using keyboard). Depending on software versions either open the menu list, scroll down to the bottom of the list and **click “Shutdown”** or **click power icon** on the toolbar

2. **Shutdown PC and projector** – both should **automatically shutdown** with the above process. If the projector does not shutdown automatically press the button on the front of the magic carpet, the light will go from blue to orange.

IMPORTANT – wait for the projector power button to change to RED before disconnecting the power – this gives the bulb adequate time to cool.