

Getting Started Guide



Bluetooth speaker with SD Card

Overview

- Wireless Connection to iPads, phones and other devices via Bluetooth as well as wired aux input.
- MicroSD Card playback
- Powerful Speaker (3W)
- Lithium-ion Battery (up to 3hrs)
- Lightweight & Rugged Design

Step by Step – using the SD card

1. Copy music files from your PC or laptop onto your Micro SD card. You may have an SD card slot on your device (you might need to put the micro SD card into an adapter) or if the laptop has no SD slot you will need a USB adapter.



*ensure the files are in MP3 format. Windows media player and iTunes both have functions to convert files to MP3 if required.

2. Turn the speaker on using the on/off switch



3. Insert the MicroSD card into the slot on the speaker



4. The speaker should say "Card Player" to indicate it is playing in card player mode. If it says "Bluetooth" you may need to take the card out and put it back in or turn the unit off and on again.

5. The speaker will start playing the music automatically.
6. To skip forward or back a track click on the V+ or V- buttons once. To change the volume of the speaker click and hold the V+ and V- buttons.
7. You can pause the music by clicking the Play /pause button.



Using Bluetooth

8. If there is no card in the speaker it will go into Bluetooth mode and flash red. Go to the settings – Bluetooth section of the device you want to pair it with and select "IBT-1". The speaker will say "Connected" and the blue light will stay constant when it is successfully connected to your device.

Charging the unit

9. The speaker can be charged by plugging the USB lead into a powersupply and to the speaker. To preserve the battery life, switch the speaker off when not in use.