

Getting Started Guide



Mobile entertainment Unit – projector and screen

Overview

- The mobile entertainment unit has an integrated projector and a mobile projector screen.
- This enables you to set up the unit anywhere; allowing the mobile entertainment unit to be accessible for all.

Step by Step – Set up Projector

1. Plug in the mobile entertainment unit – this will provide power to all the devices in the entertainment unit including the projector.
2. The projector is on an mobile arm. Remove the velcro fixing it in position and carefully let the arm raise.
3. Remove the cap of the projector
4. If your mobile unit has two games consoles ensure the correct HDMI cable is connected to the back of the projector (they are labelled). If you want to change which is projected then just change the cable over. Note that the speaker is also plugged into the back of the projector.

If you only have one games console then this will be permanently connected.

5. Turn on the projector.
6. Position the projector as required using the ball joint under the projector. It will automaticcally resize at differing angles such as on the wall or ceiling. Focus as required using the dial
7. To turn the projector off, press the off button and put the cap back on the lens of the projector.
8. Pull the arm using the loop at the joint of the arm strongly so that it lowers. Secure it using the velcro.



Step by Step – Set up Projector screen

1. Position the projector screen in the desired location and open the feet on the reverse.
2. Raise the pole on the back of the projector screen and hook the screen onto the top of the arm.
3. There are two green buttons on the pole. Depress the top green button and extend the pole. Depress the bottom green button and extend the pole.
4. Reverse the process to put the projector away.

Speaker

1. There is a speaker connected to the projector, this should automatically turn on but should it not then press the power button and adjust the volume controls using the + / - button